

MC4 and MC4-Evo2 Test Plugs

Test Plug MC4

This test plug is used to control the correct location of the MC4 contact in the insulation.



Test Plug MC4-Evo2

This test plug is used to control the correct location of the MC4-Evo2 contact in the insulation.

